SUBJECT: Feedback Between Pan Display and IF Out DATE: 7/25/78

We have found a few cases of feedback when the pan display option was installed in the SM-220 Station Monitor. This is due to the isolated ground of the BS-5 or BS-8 pan display option. It may be remedied by grounding the case of the input transformer in the BS-5 or BS-8 to the case. (See drawing below.) This change will be incorporated in all future deliveries of the BS-5 and BS-8.

