

SERVICE BULLETIN

from: TRIO-KENWOOD COMMUNICATIONS, INC.

TR-7800

#828

SUBJECT: TR-7800 TONE PAD CONVERSION FOR 4th
COLUMN FUNCTION.


DATE 6/3/80

Users who desire ABCD control functions may be accommodated by an alteration to the Control unit and to the REV switch. This switch will then perform dual functions.

1. Remove top and bottom covers, 4 screws each.
2. To free the front panel, remove 4 screws securing the front panel bracket to the side frame.
3. Unplug 5 multiconnectors from the Control unit along the front and left edges of the board.
4. Remove 6 screws from the Control unit and swing the board over.
5. Remove and save R51 22k Ω located between IC's Q19 and Q28. (Q28 pin 5).
6. Resolder this 22k Ω resistor to Q28 pin 5, and solder another 22k Ω resistor to Q28 pin 9. Using a short piece of hookup wire, extend these connections to the REV switch as shown.
7. Connect a line from the center switch contact to the original feed point of R51, which is the B3 line.
8. To reassemble, reverse steps 4 through 1.

To operate the ABCD column, hold the REV switch IN and key the 3,6,9 or #keys. Normal 3rd column tones are supplied when the REV switch is not depressed. The receive REV function is not altered by this change.

NOTE: This switch is a DPDT and may have both sets of contacts bridged. Free one set of contacts for this new function.



TRIO-KENWOOD
COMMUNICATIONS, INC.

1111 WEST WALNUT STREET - COMPTON, CALIFORNIA 90220
MAILING: P.O. BOX 7065 - COMPTON, CALIFORNIA 90224